



Precision Digital Kitchen Scale



EatSmart Products
Seattle, WA 98134

INTRODUCTION

Thank you for purchasing an EatSmart Product. Your EatSmart Precision Digital Kitchen Scale has been specifically designed for your use, with an easy to use interface and superior EatSmart accuracy and design.

Your EatSmart Precision Digital Kitchen Scale comes with the following:

- EatSmart Digital Kitchen Scale
- Instruction Manual
- 1 - 3 volt CR2032 Lithium Battery
- 2 Year EatSmart Guarantee

Please read this instruction manual carefully before using your scale.

Please fill out your purchase information for future reference:

Date Purchased: _____

Place of Purchase: _____

Order ID (if any): _____


OPERATION

Battery Installation & First Time Setup

This scale operates on 1 – 3 volt CR2032 lithium battery (installed). There is a strip under the lithium battery cover to prevent battery drain in shipping. Please remove the strip before continuing with these instructions (you may need to remove the battery compartment cover to avoid breaking the strip). Also, some models have a static cling label on the lens to prevent scratching. Please remove before use.

Replace the battery when the scale displays “LO” or readings become dim or irregular. To replace the battery:

1. Use one 3 volt CR2032 lithium battery.
2. Remove screw (or screws) from the battery compartment cover on the bottom of the scale and remove the cover.
3. Remove the old battery from the compartment.
4. Place the new battery with the “+” sign up into the battery compartment.
5. Replace the battery compartment cover and screw(s).



Note

New batteries should last for approximately one year under moderate use (less than three times daily).

Battery Warnings

NOTE: Please recycle or dispose of batteries per local regulations.

WARNING: Batteries may pose a choking hazard. As with all small items, do not let children handle batteries. If swallowed, seek medical attention immediately.

PRECAUTION: Do not dispose of batteries in fire. Batteries may explode or leak. Remove the batteries if the scale will not be used for a long period of time.

Weighing Operation

1. Place your scale on a hard, flat surface and press the “ON/TARE” button to turn on.
2. The display will show “-18888” and then switch to “0g” or “0.0 lb oz” depending on measurement unit setting. The scale is now ready for use.
3. This scale has 2 units of measurement: grams and pounds/ounces. To switch the measurement unit, press the “g/lb” button while the scale is turned on.
4. Place the item to be weighed onto the platform. The weight will display. As you add weight, the weight displayed increases.
5. When the weight is removed, the display will return to zero. The scale will turn off automatically after 1 minute. Press and hold the “ON/TARE” button to turn the scale off manually.

Tare Operation

You may wish to weigh ingredients in a bowl or other container (not included). In this case, you will need to tare, or offset, the weight of the bowl so that only the weight of the ingredients is displayed.

1. Choose a container that will safely balance on the platform without tipping or falling. Do not use a heavy container, as this might reduce the maximum capacity of the scale.
2. Press the “ON/TARE” button and the display will read “0.0 lb oz”. Place the container on the scale and press “ON/TARE” again to reset the scale to “0.0 lb oz”.
3. Add the ingredient to be weighed. The weight of the ingredient alone will display.
4. The weight of additional ingredients may be tared out as well. For example, if a recipe calls for $\frac{1}{2}$ lb rice and $\frac{1}{2}$ lb beans, place the rice into the bowl. Once the correct amount of rice is weighed, press the “ON/TARE” button until the display resets to zero. Add $\frac{1}{2}$ lb of beans. Both ingredients have been accurately weighed in the same bowl. This step can be repeated until the max load capacity (11lb/5000g) has been reached.
5. When weights have been tared out, the display will show a negative number when the items are removed from the scale.

SPECIFICATIONS

Model: EatSmart Precision Digital Kitchen Scale - ESKS-12

Capacity: 11 lbs / 5000 g

Measurement Units: Grams / Ounces / Pounds

Graduation: 1 gram / 0.05 ounces

Low Battery Indicator "LO"

Overload Indicator "oL"

Unit Dimensions: Approximately 9" x 6 3/8" x 5/8"

Unit Weight: Approximately 8 ounces

Power: 1-3 volt CR2032 Lithium Battery

WARRANTY

The EatSmart warranty covers defects in material and workmanship of the product under normal use for a period of two (2) years (excluding batteries) from the date of retail purchase. The warranty does not cover damages resulting from misuse, abuse, immersion, normal wear and tear or unauthorized modification.

Should this scale require service (or replacement at our option) while under warranty, please contact EatSmart for return authorization and troubleshooting.

There are no expressed warranties except as listed above. This warranty gives you specific legal rights which may vary from state to state. NOT LEGAL FOR TRADE.

Made in China.

EatSmart

1-866-843-3905 (8 to 5 MST)

www.eatsmartproducts.com

TROUBLESHOOTING

PROBLEM	SOLUTION
Low battery indicated “LO” No power	Check battery for proper installation (polarities are correct). Replace worn battery.
Overload indicated “oL”	Too much weight has been placed on the scale and it is overcapacity. Remove weight
Other conditions	Call 1-866-843-3905 (8AM to 5PM MST) or email, support@eatsmartproducts.com

CARE & MAINTENANCE

To protect your EatSmart Kitchen Scale in the best possible condition follow these directions as closely as possible.

- 1. Store and operate the unit in safe dry location.**
Drastic changes in temperature over time can affect the quality of weight measurement. Do not expose to direct sunlight, extreme hot/cold or humidity.
- 2. Clean with a soft, damp cloth.** Avoid abrasive cleaners and never sink or submerge in water.
- 3. Remove batteries in not in use for three months or longer.**
- 4. Use unit consistent with instructions provided in the manual.**



EatSmart Products



EatSmartScales



EatSmart Products



EatSmart Products

www.eatsmartproducts.com



ESKS-12
CPESKS12 08.16
WC